

the fold to prevent the sachet from sticking.
After use place a piece of paper between
known dealer.
direct from the manufacturer or from any well
sachet a replacement can be obtained either
Should it be necessary to renew your
side towards the glass.

**Only remove the sachet if absolutely
necessary. Replace the sachet with the shiny**

the stamp and pressing as normal.
by inserting a piece of white paper in place of
the sachet has not been accidentally punctured,
Occasionally check before use, to ensure
in the picture.

Keep the detector clean as particles on the
surface may damage the sachet or cause lines
any item being examined.

responsibility for any damage whatsoever to
despatch and, therefore, we cannot accept any
detector. Every detector is checked before
manufacturer to ensure your safe use of the
of stamps. Every care has been taken in
The detector will check many thousands

CARE OF YOUR INST-A-TECTOR

For prolonged study of watermarks and
for finding watermarks of stamps affixed to
postcard, cover or piece, the Morley-Bright
Roll-a-tector will give excellent results. Ask
your dealer for a demonstration.

PRINZ PUBLICATIONS UK LTD
UNIT 3a HAYLE INDUSTRIAL PARK,
HAYLE,
CORNWALL,
TR27 5JR
TEL: (01736) 751910
EMAIL: info@prinz.co.uk

small platform.
to examine any item which is larger than the
We recommend that you do not attempt
paper.

all foreign matter, i.e. remnants of hinges or
For best results stamps should be free of
manufacturer.

has been impressed onto the stamp during
possible that only part of the watermark
the stamp. In case of modern stamps it is
The detector can only reveal what is on
for 'grills'.

examining an embossed stamp or examining
Do not exert excessive pressure when

GENERAL INFORMATION

THE MORLEY - BRIGHT *INST - A - TECTOR* **USING YOUR INST-A-TECTOR**

The Inst-a-Tector has been designed for
simplicity of use. Practice first of all with an
easily distinguishable watermark, e.g. large
crown of GB, until you master the technique.

**Open the detector with the long edge
towards you.**

**Press the sachet hold gently with your
thumbs to move the fluid to the centre.**

**Place a stamp, face downwards, on the
small platform. Close the detector with
viewing screen uppermost. Gently squeeze,
by pressing the area on either side of the
screen with the thumbs, until the picture
of the watermark appears.**

As an aid to detecting watermarks on
difficult stamps place the strip of plastic on top
of the small platform, with the stamp positioned
on the top of this, before closing. (The strip
can be fixed permanently by inserting it into
the slots on either side of the small platform).

This is particularly useful with recessed
printed stamps, where the printing can be
more predominant than the watermark and
with heavy textured papers.